

SIGHTCARE



CloverAir

Low Vision AR Glasses

User Guide

REV1.2

Contents

Precaution	1
Quick Start.....	2
Basic Operation	9
Image Operation	13
OCR/TTS	16
Screen Mirroring	18
Open.....	19
Setting	24
Specification	26

Precaution



Charge before first use. Refer to the **Battery Charging** section for more details.



Do not expose the device to high temperatures or sunlight for a long time, and try to use it in an environment with a temperature range of 10° and 35°C (50° and 95°F).



The device is not waterproof, keep it dry and away from liquids and chemicals, and try to use it in an environment with a relative humidity of less than 70%.



Do not attempt to repair the device. Any unauthorized attempt will void the product warranty. Please contact with your distributor.



Please use the battery, charger and data cable that comes with the device, and the compatibility of other unofficial accessories is not guaranteed.

Quick Start

Overview

The **CloverAir** series is a glassed-style electronic video magnifier focused on improving vision perception for visually impaired person. It provides clear image quality while offering unrestricted portability, supporting mobile use in all indoor and outdoor scenarios.

The **CloverAir** low-vision AR glasses use a modular design that separates the computing unit, battery, and display optical module into two independent parts, greatly reducing the weight of the glasses (around 80g) and heat generation (around 30°C), improving comfort for long-term wear. The glasses are creatively equipped with dual cameras. The front main camera captures visual information such as text and objects and processes it through algorithms to achieve image magnification, contrast enhancement, and color optimization. The processed image is then projected onto the glasses' binocular HD OLED display module. When switched to the close-up camera, users don't need to lower their heads excessively to capture content on a desk, greatly improving the experience of reading and writing on paper at a desk.

In addition, **CloverAir** is equipped with OCR, mobile screen mirroring, external HDMI input, and a variety of other features and interfaces to seamlessly meet the daily needs of visually impaired person.

Compositions

- Head-mounted Display



1. AR display module

2. Nose pad

3. Diopter knob

4. USB Type-C port




5. Main camera



6. Close-up camera

● Visual Processing Box



1. Power/TTS button 

2. Zoom Out button 

3. Color button 

4. Zoom In button 

5. Joystick  /Enter

6. Freeze button 

7. Lookup/Enter button 

8. Switch/Return button 

9. Button lock 

10. Shift button 

11. MicroSD card slot

12. HDMI Input

13. DC charging port


14. Signal port

15. Lightning port

Accessories



User Manual



Power Adapter




Sunshade

Nose Pad

Glasses Anti-slip Sleeves

Wire Clamp

Cleaning Cloth



Wireless Bluetooth Earphones

Lightning to USB-C
Screen Mirroring Cable

USB-C to Lightning Adapter

HDMI-C to HDMI-A Cable

USB-A to USB-C
Earphone Charging Cable

Eyewear Fitting

- **Nose Pad**


- 1) Setup**

The nose pad offers 3 adjustable positions.


- Align the nose pad connector with the frame slot.
- Insert it straight into your preferred position until it locks

into place.

- c) Adjust the nose pad arms to make them fit more closely against the nose.



Position 1



Position 2




Position 3



Nose pad arm adjustment

2) Nose Pad Cushion Adjustment

- a) The soft cushions on the nose pad can be adjusted vertically for a customized fit. Gently slide the cushions up or down along the support arm.




- b) The nose pad cushions can be rotated outward or inward to match the contour of your nose. Simply grasp the cushions and pivot them to the position.



● Eyeglass Temple


The temple can be adjusted within a $\pm 5^\circ$ range for a personalized fit. Gently bend the temple upward or downward to your desired angle until it rests comfortably against the side

of your head.



- **Myopia Diopter**

Rotate the diopter knob to adjust the Myopia diopter (from 0° to 600°) for clearer vision.



- **Sunshade**

Align the sunshade with the magnetic positions on the frame, until it clicks magnetically.





Battery Charging

Connect the supplied power cable to the DC port of Visual Processing box, and plug power adapter into an AC outlet to start charging. The green light is on when charging, and the green light is off when it is fully charged in the shutdown state.

Basic Operation

Power On / Off

Connect the Head-mounted Display and Visual Processing Box using the supplied USB-C to USB-C signal cable.

Press and hold the Power/TTS button  for 2 seconds to turn on/off the device.



Button Lock

Slide the Button lock  to lock or unlock the button operations (except for power on/off).

Quick Control Bar

Short press the Shift button  to pop up/close the quick control bar. Push and short press down the Joystick  or the

Lookup/Enter button  to select the related function or setting.

Press the Zoom In button  or Zoom Out button  to adjust the setting, and short press the Lookup/Enter button  or the Switch/Return button  to confirm.

Line Mask	Image Exposure	Screen Brightness	Bluetooth Volume			
						
Focus Control		Battery Status		Image Contrast		

Main Menu

Press and hold the Switch/Return button  for 2 seconds to exit the current module and enter the Main Menu. Push and short press down the Joystick  or short press the Lookup/Enter button  to enter the following modules:

Magnifier - Open - Setting

Display Switching

Short press the Switch/Return button  to switch between: Main camera display, Close-up camera, HDMI Input and Mirroring.

The device supports external HDMI audio and video input with 1920*1080 video resolution.

Bluetooth and Volume

When no Bluetooth audio device is connected, click the

Bluetooth icon  on the Quick Control Bar to pair and connect the scanned Bluetooth headphones or speakers.

When Bluetooth audio device is connected, click the volume

icon  on the Quick Control Bar to adjust the volume.

Bluetooth audio device can be switched by pushing and short pressing down the Joystick  or the Lookup/Enter button 

to click the Bluetooth icon  on left side of the volume bar.

Image Operation

Image Scaling

Press the Zoom In button  or Zoom Out button  to zoom in or zoom out the image.

Enhanced Color / Edge Mark

Short press the Color button  to switch between different edge marks and enhanced color combinations.

Edge marks and color combinations can be customized in the **setting** module.

Press and hold the Color button  for 2 seconds to quickly return to the natural color.

Press and hold the Shift button , and short press the Color button  to change the color of edge mark.

Image Freeze / Storage

Short press the Freeze button  to freeze the image at a higher quality.

Press and hold the Freeze button  for 2 seconds to pop up the saving checkbox and choose to save the image.

Short press the Freeze button  again to unfreeze the image.

Image Lookup

Short press the Lookup/Enter button  to reduce the image to 1/3 of the current size, and short press again to return.

Press and hold the Lookup/Enter button  to reduce the image to the minimum zoom level, and release to return.

Image Panning

Push the Joystick  to navigate the image around. **Head movement tracking** can also be used to navigate the still image.

● Panning Speed Adjustment

Keep pushing the Joystick  to any direction and short press the Zoom In button  or Zoom Out button  to pop up and adjust the Panning Speed Bar.

● Picture Positioning

Quickly push the Joystick  in the same direction twice to jump to the image edge directly.

In the **Mirroring** module or when HDMI input, press down the Joystick  to Jump to the upper left corner of the image. In the **other** modules, press down the Joystick  to jump to the image center.

Image Focus

Press and hold the Shift button  for 2 seconds to trigger the focus manually.

Click the Focus Control icon  on the Quick Control Bar to toggle between autofocus and focus lock which is especially useful for handwriting or handwork to prevent the fault focus on the hand or pen.

Reading Line/Mask

Click the Line Mask icon  on the Quick Control Bar to toggle between horizontal reading line, vertical reading line and reading mask.

Press and hold the Shift button , and push the Joystick  to change the position or the thickness of reading line/mask.

Press and hold the Shift button , and short press the Color button  to change the color of reading line.

Image Exposure

If the exposure of camera is affected by the environment being too bright or too dark, click the Image Exposure icon  on the Quick Control Bar to pop up the exposure control bar.

Exposure Value = 0

Auto Exposure



Exposure Value ≠ 0

Manual Exposure



OCR/TTS

Abbreviation: OCR (Optical Character Recognition); TTS (Text to Speech); Before OCR recognition, set the corresponding language type in the Language Setting Page.

Short press the Power/TTS button  to pop up the OCR checkbox.

After confirmation, the current image will be recognized and the text will be converted to speech and start reading aloud.

Click the Exit icon  or press and hold the Switch/Return button  for 2 seconds to exit reading aloud.

TTS Control Bar

Short press the Shift button  to pop up the TTS control bar together with the quick control bar.



TTS Operation

- **Play / Pause:** Click the play/pause icon  or short press the Power/TTS button  to play or pause the reading aloud.

- **Picture / Plain Text Read-aloud:** Short press the Switch/Return button  to choose to read aloud in picture mode or plain text mode. Only the text of the current section is displayed with segmentation enabled, and the whole recognized text is displayed with segmentation disabled.
- **Skip lines:** Press and hold the Shift button , and short press the Zoom In button  or Zoom Out button  to jump to the previous or next section or sentence. Press and hold the Lookup/Enter button  for 2 seconds to activate the cursor and use **Head movement tracking** to jump to different sections or sentences and release the Lookup/Enter button  to start reading aloud.


Screen Mirroring

Android smartphone/pad with **MirrorPlay** APP installed can be screen casted. iPhone/iPad can be screen casted without additional APP installed.

Use the official USB type-C / Lightning cable to connect the

phone and the device, and the device will automatically detect and enter the **Mirroring** module.

If the following user interface appears on the device screen, perform the following operations.

	Please open the MirrorPlay APP on Android smartphone and authorize screen casting. If it is not working, please try reconnecting the USB Type-C cable.
	The phone is in the lock screen state, please unlock the phone.


Open

Recognized image formats: JPG, BMP, PNG

Recognized document formats: TXT, PDF

Supported file systems: FAT32, exFAT

Storage Medium



Memory



MicroSD Card

- Push and short press down the Joystick  or short press the Lookup/Enter button  to choose the storage medium and open the folder of selected storage medium.
- The memory folder can be formatted. Select and highlight the folder, press and hold the Shift button  for 5 seconds to pop up the format checkbox , short press the Shift button  again to format the folder, or press the other buttons to cancel the formatting.

Note: The formatting will erase all files in the selected folder, so please do it carefully and make a backup.

Thumbnail Grid

- Push the Joystick  to turn the page up and down when in the image or document folder of selected storage medium. Short press the Switch/Return button  to return to the parent directory. Short press down the Joystick  or the Lookup/Enter button  to open the selected file.
- Press down and hold the Joystick  or the Lookup/Enter

button  for 2 seconds to activate or inactivate the multi-selection for files. Push and short press down the Joystick

 or the Lookup/Enter button  to select the images or documents which can be transferred or deleted in batches.

- Files can be copied from different storage medium. Files from internal memory can be exported to an SD card by short pressing the Freeze button . Files from the SD card can also be imported into the Shared Picture or Shared Document folder of internal memory by short pressing the Freeze button .
- Press and hold the Freeze button  for 3 seconds to copy all files in batches.
- Short press the Shift button  to pop up the delete prompt on the highlighted thumbnail. Short press again to confirm the deletion or press other buttons to cancel.
- Press and hold the Shift button  for 5 seconds to delete all pictures or documents in this folder. Short press again to confirm the deletion or press other buttons to cancel.


- The thumbnail of the image saved in the OCR/TTS module will appear with an embedded text icon  in the upper left corner. Short press the Zoom In button  to open the text attached to the image.

File Control Bar

Short press the Shift button  to pop up the file control bar together with the quick control bar. Push and short press down the Joystick  or the Lookup/Enter button  to click the highlighted icon.

Click the Exit icon  or press and hold the Switch/Return button  for 2 seconds to close the file and return to the thumbnail grid.

- Picture Control Bar:



- **TXT Control Bar:**



- **PDF Control Bar:**



- Click the image rotation icon  or short press the Freeze button  to rotate the image.
- Automatic pagination for the large TXT format document.
- The PDF document may also contain TXT text information, click the PDF mode icon  or the TXT mode icon  to switch between each other. If the current PDF page does not contain TXT format text, an Empty TXT icon  is displayed.
- Click and hold on the Page Up icon  or Page Down icon  to turn multiple pages at once.

Setting

Option Page



Color Mode Combination: Customize the desired color mode from 12 selectable color combinations and 2 edge marks.



Enable or disable the Close-up camera.



Enable or disable Text to Speech.



Language Setting: Set the target region and language for OCR.



Male and female voice selection.

Factory Setting Page



System Reset: Restore the default factory settings.



Power Frequency: The power frequency can be manually set to 50HZ or 60HZ according to different countries and regions.



User Interface: Standard UI mode provides comprehensive functionality; Simple UI mode disables most combo key functions as well as other complex features such as image saving, playback, line mask, joystick live panning, and OCR.

Hardware Reset

When the device is hung or can't be turned off normally, press down the Power button  and Zoom In button  and Zoom Out button  at the same time to trigger the hardware reset.

Specification

Model:	CloverAir
Optical system:	AR Birdbath
Field of view:	FOV43° @0D
Eye box @ Eye relief:	10*7mm@12mm
Dioptr:	-6D ~ 0D
Display panel:	0.49-inch Mirco-OLED, 1920*1080
Perceived brightness:	100 to 400 nits adjustable
Interpupillary distance:	53 to 73 mm
Main camera:	Standard 48MP
Close-up camera:	Telephoto 24MP
Magnification:	Near: 1.2x - 30x; Distance: up to 30x
Color mode:	Nature color; Edge mark; False color
Connection:	SD; Lightning; HDMI IN; Bluetooth
Battery:	6000 mAh Li battery; 7 hours duration
Power Adapter:	Input: 100-240V; Output: 5V/3A
Weight:	≤ 80g (Glasses); ≤ 185g (Box)
Dimension:	≤ 155*57*48mm (Glasses folded) ≤ 155*168*48mm (Glasses unfolded) ≤ 160*53*21mm (Box)



Ver.

Low Vision

SIGHTCARE